

Start/Stop set CordlessControl, type F (630231000)

Order no. 630231000 EAN 4061792192645



CORDLESS

Product may differ from Image

- When starting upshutting down the cordless tool, the connected mains-powered vacuum cleaner starts/stops automatically
- Compatible with standard cordless, mains-powered tools and vacuum cleaners available on the market
- Manual starting of the vacuum cleaner is also possible with the remote button at the coupling bush of the hose
- "Vibration detection" function at the transmitter permits automatic start-up/shut-down of the vacuum cleaner by detecting vibrations
- If the vibrations are too low, the transmitter can be connected directly to to the extracting tool using the multi tape
- Multi tape to fix the transmitter to all standard hose diameters
- Start/stop cordless control replaces the function of the integrated power socket for a mains-powered tool

Technical data

Characteristics

Radio frequency	2402 - 2445 Mhz
Mains voltage	220 - 240 V
Power supply transmitter	CR2032
Signal strength	- 6 dBm

Scope of delivery

Receiver socket, transmitter, 3x multi tape, battery CR 2032