

Batterier for hagen.

Bruk	Maskin	Tilbehør	Batteri						
			Li-Power			LiHD			
									
2.0 Ah	4.0 Ah	5.2 Ah	4.0 Ah	5.5 Ah	8.0 Ah	10.0 Ah			
Kutte hekken			Hekksakser / busksakser						
	SGS 18 LTX Q	Buskkniv	165 min	330 min	430 min	330 min	455 min	660 min	825 min
	HS 18 LTX 45 / HS 18 LTX 55 / HS 18 LTX 65		48 min	96 min	125 min	96 min	132 min	192 min	240 min
	HS 18 LTX BL 55 / HS 18 LTX BL 65 / HS 18 LTX BL 75		16 min	33 min	43 min	33 min	45 min	65 min	82 min
	MA 36-18 LTX BL Q + MA-HS 50 (trinn 1)		27 min	55 min	71 min	55 min	75 min	109 min	136 min
	HS 18 LTX 45 / HS 18 LTX 55 / HS 18 LTX 65		17 min	34 min	44 min	34 min	47 min	68 min	85 min
	HS 18 LTX BL 55 / HS 18 LTX BL 65 / HS 18 LTX BL 75		13 min	27 min	35 min	27 min	37 min	54 min	67 min
	MA 36-18 LTX BL Q + MA-HS 50 (trinn 2)		20 min	39 min	51 min	39 min	54 min	79 min	98 min
Saging			Beskjæringssag/ kjedesag/ stangsag						
	MS 18 LTX 15	Sagskinne + sagkjede 15 cm (1/4" / 1,1 mm)	60 snitt	120 snitt	156 snitt	120 snitt	165 snitt	240 snitt	300 snitt
	MS 18 LTX 15 + Teleskopstav MS		48 snitt	96 snitt	125 snitt	96 snitt	132 snitt	192 snitt	240 snitt
	MA 36-18 LTX BL Q + MA-MS 25 (trinns 2)	Sverd + sagkjede 25 cm (3/8" LP / 1,3 mm)	70 snitt	140 snitt	182 snitt	140 snitt	193 snitt	280 snitt	350 snitt
	MS 36-18 LTX BL 40	Kjede- og sverdsett 40 cm (3/8" LP/1,1 mm)	62 snitt	125 snitt	162 snitt	125 snitt	171 snitt	249 snitt	311 snitt
			18 snitt	37 snitt	47 snitt	37 snitt	50 snitt	73 snitt	91 snitt
Fjerne løv / smuss			Løvblåser						
	LB 18 LTX BL		7 min	14 min	18 min	14 min	19 min	28 min	35 min
Klippe			Gressklipper						
	RM 36-18 LTX BL 36		27 min	54 min	70 min	54 min	74 min	108 min	135 min
	RM 36-18 LTX BL 46		23 min	45 min	59 min	45 min	62 min	90 min	113 min
	RM 36-18 LTX BL 36		8 min	16 min	21 min	16 min	22 min	32 min	40 min
	RM 36-18 LTX BL 46		9 min	18 min	23 min	18 min	25 min	36 min	45 min
Klippe, trimmer og rense			Busk-gressaks						
	SGS 18 LTX Q	Gresskniv, teleskopstav	150 min	300 min	390 min	300 min	415 min	600 min	750 min
	Gresstrimmer / krattkutter								
	RTD 18 LTX BL 30	Dobbel trådspole	20 min	40 min	52 min	40 min	55 min	80 min	100 min
	FSD 36-18 LTX BL 40 / FSB 36-18 LTX BL 40		10 min	20 min	26 min	20 min	28 min	40 min	50 min
	MA 36-18 LTX BL Q + MA-FS 40 (trinn 1)		24 min	47 min	61 min	47 min	65 min	94 min	118 min
			21 min	42 min	55 min	42 min	58 min	84 min	105 min
	FSD 36-18 LTX BL 40 / FSB 36-18 LTX BL 40	Dobbel trådspole / gresskniv	9 / 12 min	18 / 25 min	23 / 32 min	18 / 25 min	25 / 34 min	36 / 49 min	45 / 62 min
	MA 36-18 LTX BL Q + MA-FS 40 (trinn 2)		8 / 11 min	17 / 22 min	22 / 29 min	17 / 22 min	23 / 30 min	33 / 44 min	42 / 55 min
	FSD 36-18 LTX BL 40 / FSB 36-18 LTX BL 40	Grovkniv	16 min	32 min	41 min	32 min	43 min	63 min	79 min
	MA 36-18 LTX BL Q + MA-FS 40 (trinn 2)		14 min	28 min	37 min	28 min	39 min	56 min	71 min
Sprøyting			Ryggsprøyte						
	RSG 18 LTX 15		4 h	8 h	10,5 h	8 h	11 h	16 h	20 h
Vanning / lensing			Senke- og regntønnepumpe						
	TPF 18 LTX 2200 (trinn 1)	Vanningspistol	55 min	110 min	143 min	110 min	151 min	220 min	275 min
		TPF 18 LTX 2200 (trinn 3)	Vannspreder	20 min	40 min	52 min	40 min	55 min	80 min
Utløpsarmatur 1" (Ø 25 mm)			17 min	34 min	44 min	34 min	47 min	68 min	85 min

Anbefalt batteri

Driftstidene kan variere med bruk, gresstype og oppladningstilstand for batteriet.

metabo[®]